FLAMEN HOT

Thank you for purchasing a Flamen Hot product.

Product Descriptions

Model Beef'ed up

Model Number 202003B

Description

This BBQ & Smoker is designed to be a real talking point. Built with extra strong components such as the thick steel handle, stainless steel smoking inserts and cast-iron grill.

Features

Recycled 44 Gallon Drum Thick 3mm Steel Frame 30mm Steel Handle 400 X 470mm Cast Iron Grill Galvanized 25mm Steel Legs 2 x Stainless Steel Smoking Inserts 325mm x 265mm 1 x Stainless Steel Meat Resting Tray 325mm x 176mm

Dimensions

Cooking Height	720mm
BBQ Height	1275mm
Width	890mm
Depth	600mm

Lighting a Fire



There is nothing more frustrating than trying to light a fire and all you are getting is the fire going out.

For a good fire you will need.

- 1. Fire Starter Cubes these should be available from your supermarket.
- 2. Kindling which is small pieces of very dry wood
- 3. Solid Firewood which your local service station should sell
- 4. Off course a lighter or matches

Place some kindling flat on the bottom of the barrel, make sure you keep the lid open while you have the fire going

Then place 3 or 4 lighter cubes on the kindling and then build a tepee over the top of the cubes.

Allow enough space between the kindling to allow air to get into the bottom of the barrel. Your tepee should not be any bigger than 40 cm X 40 cm

Light the cubes and wait until the kindling catches fire. Feed a little more kindling onto the fire once it is alight.

After 5 – 10 minutes place a larger log of your wood preference onto the fire.

We encourage you to use sustainable wood or coal bricks.



Safety Instructions

Thank you for purchasing your Flamen Hot BBQ. Your safety is very important to us so please make sure you follow the below safety instructions.

- 1. Do not use indoors
- 2. Use outdoors with a least 1.5 metres away from any flammable items
- 3. Never fill the BBQ more than ¼ full of wood or coals
- 4. Use fire starters and kindling to start the fire see fire instructions
- 5. Use fireproof gloves when adding or handling the wood or coals near the fire
- 6. Always ensure that all the components of the BBQ are fix and fastened
- 7. Always use wood that is suitable for cooking food
- 8. Have a water source or fire extinguisher handy
- 9. Never use your BBQ on a total fire ban day
- 10. Never pour oil onto the grill for cooking
- 11. Use tongs or other suitable utensils to handle food on the grill
- 12. Ensure that the smoke is blowing away from other people

Warranty



Applicable to all Flamen Hot BBQ's, Fire Pits and Smokers

Your barrel comes with a 12-month warranty and includes components, build quality and parts.

The warranty comes into effect once dispatched and out of our control.

- 1. The company will repair the product, at no cost, if the product is still under warranty
- 2. The company will repair any broken parts of a product using new or replacement parts
- 3. The product will be exchanged with a new product
- 4. The price of product will be refunded

The warranty does not cover the following,


- 1. Dints in the barrel from movement
- 2. Fading or discoloration of paint or surfaces, as this will occur due to the heat
- 3. Any misuse of the barrel other than what it was designed to do
- 4. Any damage caused by acts of nature
- 5. Damage of a product resulting from negligence
- 6. Damage of a product resulting from unauthorized modification of the product
- 7. Theft or loss of the product
- 8. Damage caused by chemicals

Attaching the Legs

You will need 1 x shifter or socket

A towel or blanket, something to rest the barrel on to protect it






Step 1

Lay the barrel on its side on a soft surface so you do not scratch it, and stand

in front of the handle. Open the barrel up so you can easily reach the back of the barrel






Step 2

Position one leg at a time over the pre-drilled holes as shown. Use the bolt and nut to tighten each leg to the barrel. Use the shifter provided as well as another shifter or socket.

Caution Ensure the legs are fastened tightly before use





Step 3

Repeat step 2 for both legs on one side, then carefully flip over the barrel and repeat

Make sure that the top of the leg has the smaller piece of leg adjacent to the barrel. It should sit flush against the barrel.

Check each nut and bolt to ensure they are tight after the first use as the metal will get hot and may contract a little. This is normal.

Step 4

Attached the cross bar on the front legs as shown, tighten

